

AUSTRALASIA




PRODUCT MANUAL

# AGD932

Target Simulator

AGD-SYSTEMS.COM.AU



# TABLE OF CONTENTS

AGD932

Target Simulator

## INTRODUCTION

Product & technology	3
Key features	3
Typical applications	4
Product overview	4

## DISPLAY / CONFIGURATION

Screen mode operation	5
Information display 342	5
Pulse/Transmit mode	5
Continuous mode	5
Screen modes	6
Start up screen	6
Select radar type	6
Setting the target speed values	7
User selectable speed values	7
Setting the radar mounting angle	8
Setting the radar range	8
Setting speed measurement – kph/mpH	9
Setting target type	9
Set to recede or advance	10
Save settings	10
Pulse/Transmit or Continuous mode	10
Low battery warning	11
Shutting the unit down	11
Information display 350	12
Pulse/Transmit mode	12
Continuous mode	12
Tracked target mode	12
Queue mode	12
Free flow mode	12

Screen modes	13
Start up screen	13
Select radar type	13
Setting the target speed values	14
User selectable speed values	14
Setting the radar mounting angle	15
Setting the radar range	15
Setting speed measurement – kph/mpH	16
Setting target type	16
Set to recede or advance	17
Modes of operation (pulse)	17
Modes of operation (continuous)	17
Modes of operation (tracked)	18
Modes of operation (queue)	18
Modes of operation (fast flow)	18
Channel frequency	19
Save settings	19
Low battery warning	19
Shutting the unit down	19

## CONFIGURATION

Adjustable parameters	20
Pre-set speed values	20

## TECHNICAL SPECIFICATIONS

Product specification	21
-----------------------	----

## CERTIFICATION

22-23

## IMPORTANT SAFETY INFORMATION

Safety precautions	24
--------------------	----

## DISCLAIMER

25

Warranty	25
----------	----



## INTRODUCTION

### PRODUCT OVERVIEW AND TECHNOLOGY

The AGD932 is a compact purpose designed portable radar target simulator that can be used to test radars on site for correct operation and speed reporting. A number of special features have been designed into the target simulator including user selectable pre-set speed values or capability to set specific speed values as required and vehicle type.

The target simulator features a number of user adjustable parameters via an intuitive user interface allowing quick and easy set up in a roadside environment.



### KEY FEATURES

- Lightweight ergonomic profile
- State-of-the-art radar technology
- Ease of set up in road side environment
- Intuitive user Interface
- User selectable pre-set speed values
- User definable specific speed values
- Battery powered (2x AA)



# AGD932


Target Simulator

# INTRODUCTION

## TYPICAL APPLICATIONS

AGD932

Target Simulator



Power on / off  
press and hold for 1  
second to power up  
or power down unit  
(auto power off after 5  
minutes)


Up / Down  
Scroll through options.  
Inverse highlighted item  
identifies the currently  
selected parameter



Information display

Select / Accept / Return  
Select highlighted option /  
accept change


Activate Test  
Audible confirmation given



Battery  
compartment  
cover – takes  
2x AA batteries


## SCREEN MODE OPERATION

The 932 menu system works on a basic principal whereby the screen will cycle through the menu options as shown below. The return button allows you to enter a menu and the up/down arrows allow you to adjust settings, pressing the return button will cycle you to the next menu option.



\*The 350 radar has extra modes available, please refer to relevant section in this manual

INFORMATION DISPLAY 342



AGD342

22°

16.0 m

Km/Hr

ADVANCE


Vehicle icons

**PULSE/TRANSMIT MODE**

Radar type

Target speed preset values or user defined

Advance (recede)



AGD342

22°

16.0 m

Km/Hr

ADVANCE

Vehicle icons

**CONTINUOUS MODE**

Radar type

Cosine (radar mounting angle)

Radar range

Speed units

Vehicle type

Save settings

If relevant to radar type

SCREEN MODES

Start up screen

On powering up the 932 will display a splash screen. The current software version is shown on the bottom left, along with the detector model the 932 has been calibrated for.



Select radar type

The screen will switch to "Select Radar" automatically, here you can scroll up or down using the arrows to select the radar you wish to test. Press return to select and move to next screen.



Please note that the orientation of the unit varies with radar type due to the e field polarisation - horizontal or vertical.

SETTING THE TARGET SPEED VALUES







The large numbers indicating the pre-set speed setting is highlighted ready for input. The default setting is 30Km/Hr, press return to make active, the numbers will flash you can use the up/down arrows to amend the speed, see the table on page 11 for the pre-set values. The presets will simply cycle through from minimum to maximum range - 20Km/Hr (12mph) to 320Km/Hr (200mph). To select the speed press the return button.

The sample screens show the minimum speed setting of 21Km/Hr and the maximum speed setting of 320Km/Hr.

NOTE: certain radars may only support certain speed values.

USER SELECTABLE SPEED VALUES



You can highlight the individual numbers, i.e. hundreds, tens and units to set your own speed measurement. Toggle through each unit then press return to set.



SETTING THE RADAR MOUNTING ANGLE

The next setting displayed is the radar target mounting angle – top right. Minimum angle is 0° – maximum is 30°, use the return button to make active and arrows buttons to alter value, either up or down. Press return again to set.


NOTE: certain radars may not require mounting angle adjustment.



SETTING THE RADAR RANGE

The radar range can be set from a minimum of zero metres to a maximum of 96 metres. The value increments will depend on the radar type.



NOTE: This function is only available on certain radar types.







SETTING MEASUREMENT – KPH/MPH

The next setting allows you to toggle between kph and mph.




SETTING THE TARGET TYPE

There are 3 options for target type, Car, Van and Lorry. Simple cycle through the options and press return to select.



SET TO RECEDE OR ADVANCE

There is a simple toggle button to select either recede or advance. Press return to select.



SAVE SETTINGS

Arrow forward to the save settings button bottom right and press return.



TRANSMIT & CONTINUOUS MODE

This option allows you to decide between transmit or continuous mode.



### LOW BATTERY WARNING

If during operation the batteries become depleted the unit will warn you with this message before automatically shutting down. Simply replace batteries x2 AA and restart to continue.

BATTERY LOW  
SHUTTING DOWN

### SHUTTING THE UNIT DOWN

Holding the power on button for more than one second will shut the unit down. We would advise removing the batteries if the unit is not going to be used for long period.

SHUTTING DOWN

INFORMATION DISPLAY 350

**PULSE/TRANSMIT MODE**

AGD350

00°

030

10.2 m

Km/Hr

MHz

24175

ADVANCE

**CONTINUOUS MODE**

AGD350

00°

030

10.2 m

Km/Hr

MHz

24175

ADVANCE

**TRACKED TARGET MODE**

AGD350

00°

030

85.2 to

03.4m

MHz

24175

ADVANCE

**QUEUE MODE**

AGD350

00°

015

10.2 m

MPH

MHz

24175

ADVANCE

**FREE FLOW MODE**

AGD350

00°

050

10.2 m

MPH

MHz

24175

ADVANCE

Radar type

Target speed preset values or user defined

Advance (recede)

Channel frequency

Radar type

Cosine (radar mounting angle)

Radar range

Speed units

Vehicle type

Save settings

Channel frequency

Radar type

Target speed preset values or user defined

Advance (recede)

Channel frequency

Radar type

Cosine (radar mounting angle)

Radar range

Speed units

Vehicle type

Save settings

Channel frequency

Radar type

Cosine (radar mounting angle)

Radar range

Speed units

Vehicle type

Save settings

Channel frequency

If relevant to radar type

If relevant to radar type

If relevant to radar type

SCREEN MODES

START UP SCREEN

On powering up the 932 will display a splash screen. The current software version is shown on the bottom left, along with the detector model the 932 has been calibrated for.



SELECT RADAR TYPE

The screen will switch to “Select Radar” automatically, here you can scroll up or down using the arrows to select the radar you wish to test. Press return to select and move to next screen.



Please note that the orientation of the unit varies with radar type due to the e field polarisation – horizontal or vertical.

SETTING THER TARGET SPEED VALUES




The large numbers indicating the pre-set speed setting is highlighted ready for input. The default setting is 30Km/Hr, press return to make active, the numbers will flash you can use the up/ down arrows to amend the speed. See the table on page 11 for the pre-set values. The presets will simply cycle through from minimum to maximum range – 21Km/Hr (12mph) to 320Km/Hr (200mph). To select the speed press the return button.

The sample screens show the minimum speed setting of 21Km/Hr and the maximum speed setting of 320Km/Hr.

NOTE: certain radars may only support certain speed values.

USER SELECTABLE SPEED VALUES




You can highlight the individual numbers, i.e. hundreds, tens and units to set your own speed measurement. Toggle through each unit then press return to set.



SETTING THE RADAR MOUNTING ANGLE

The next setting displayed is the radar target mounting angle – top right. Minimum angle is 0° – maximum is 30°, use the return button to make active and arrows buttons to alter value, either up or down. Press return again to set.




NOTE: It is advised to use the radar in a setting of 0° for the 350 radar. Please ensure to also set the mounting angle correctly in the radar.



SETTING THE RADAR RANGE

The radar range can be set from a minimum of zero metres to a maximum of 85.2 metres. The value increments will depend on the radar type.



NOTE: This function is only available on certain radar types.








SETTING MEASUREMENT - KPH/MPH

The next setting allows you to toggle between kph and mph.



SETTING THE TARGET TYPE

There are 3 options for target type, Car, Van and Lorry. Simply cycle through the options and press return to select.







# DISPLAY / CONFIGURATION

AGD932

Target Simulator

## SET TO RECEDE OR ADVANCE

There is a simple toggle button to select either recede or advance. Press return to select.





## MODES OF OPERATION (PULSE)

This option allows you to choose between five modes in the 350 radar:

Pulse/transmit Mode:

This mode is selected by highlighting the mode of operation icon. Selecting this mode will then give the option of adjusting the pulse time. This value is adjustable between 100ms and 1000ms in 100ms steps. To adjust the on-screen value, select using the return key and adjust the value using the up/down keys. Hitting return will exit to the main screen with the selected value.




## MODES OF OPERATION (CONTINUOUS)

This option allows you to choose between five modes in the 350 radar:

Continuous Mode:

This mode is selected by highlighting the mode of operation icon. Selecting this mode will then give a continuously repeated target which has a one second off period before re-transmitting. There are no adjustable parameters associated with this mode.





MODES OF OPERATION (TRACKED)

This option allows you to choose between five modes in the 350 radar.

Tracked Mode:

This mode is selected by highlighting the mode of operation icon.

Selecting this mode will generate a target either advancing or receding that steps in range toward or away from the radar. Upon selecting the 'tracked target' icon, the screen will display a low and high range figure in metres. Simply press the down arrow to accept these figures and move back to the home screen, or hit the return key on the highlighted parameter to adjust. Pressing the down arrow after adjustment will return to the home screen



MODES OF OPERATION (QUEUE)

This option allows you to choose between five modes in the 350 radar:

Queue Mode:

This mode is selected by highlighting the mode of operation icon.

Represented as Q15 in the display, selecting this mode will simulate a target with a pre-set speed of 15mph, pulsed as such to generate a queue when using the queue detection function in the 350 radar. Both speed and direction may be adjusted when using this parameter.



MODES OF OPERATION (FAST FLOW)

This option allows you to choose between five modes in the 350 radar:

Fast Flow Mode:

This mode is selected by highlighting the mode of operation icon.

Represented as F50 in the display, selecting this mode will simulate a target with a pre-set speed of 50mph, pulsed as such to release the queue generated using the above queue function when using the queue detection function in the 350 radar. Both speed and direction may be adjusted when using this parameter.




## SETTING THE CHANNEL FREQUENCY

This option allows you to select one of six transmit frequencies. Highlighting the transmit frequency in the display, select using the return button and using the arrows, the device can cycle through and select the following frequencies:


24.077GHz, 24.125GHz, 24.175GHz, 24.223GHz for CE marked models of the 350.

24.102GHz and 24.148GHz for FCC marked models of the 350.




## SAVE SETTINGS

Arrow forward to the save settings button bottom right and press return.




## LOW BATTERY WARNING

If during operation the batteries become depleted the unit will warn you with this message before automatically shutting down. Simply replace batteries x2 AA and restart to continue.



## SHUTTING THE UNIT DOWN

Holding the power on button for more than one second will shut the unit down. We would advise removing the batteries if the unit is not going to be used for long period.



# CONFIGURATION

AGD932

Target Simulator

## ADJUSTABLE PARAMETERS


PARAMETER	VALUE / RANGE	COMMENTS
Cosine	0° – 30°	
Speed	20 – 320 kph	Pre-set or user adjustable
	(4 – 262 kph for 350 radar)	
Speed units	kph / mph	User selectable
Target direction	Advance / recede	User selectable
Operating mode	Single burst / pulsed / continuous	Audible indication provided
	/ tracked / queue / free flowing	(whilst simulating signal is active)
Vehicle type	Small / Medium / Long	Depicted as Car / Van / Lorry
Radar type		Select radar model number
Range		Pre-set range value available on select model type

## PRE-SET SPEED VALUES

SPEED KPH	SPEED MPH
21	13
38	24
50	31
64	40
82	51
97	60
110	68
131	81
250	150

In addition to the pre-set speed values, user adjustable speed values between 20kph (12mph) and 320kph (200mph) can be set (4 – 262kph for 350 radar).

**NOTE:** standard operating distance is between 1 and 2 metres from detector face. Use outside of this recommended operating distance may result in data errors.



SPECIFICATIONS

Frequency	K-Band 24GHz
Simulation Range	20 – 320 kph (4 – 262 kph for 350 radar)
Operating Time	10 hours continuous use
Operating Distance	Min 1m – Max 2m
Mounting	Flange fixings or tripod mount
Mounting Height	1 – 3.5m nominal
Housing Material	Polycarbonate
Sealing	IP52
Operating Temp	-20° C to +50° C
Power	40mA (120mA Transmit)
Power Supply	2.2V – 3.6V (2 x AA Batteries)
Approved to	BS EN 50293 EN 301-489 ETSI EN 300-440 AS/NZ 4268:2003

Standard operating distance is between 1 and 2 metres from detector face. Use outside of this recommended operating distance may result in data errors.

Owing to the Company’s policy of continuous improvement, AGD Systems Pty Ltd reserves the right to change their specification or design without notice. AGD products should be installed by a competent person.



# CERTIFICATION

AGD932

Target Simulator



**CERTIFICATE OF CONFORMITY & COMPLIANCE**

PURPOSE OF TEST: Radio Performance Testing

TEST SPECIFICATION(s): AS/NZS 4269:2003

TEST RESULT: Compliant to Specification

EQUIPMENT UNDER TEST: AGD932

BAND(s) OF OPERATION: 24.00 GHz – 24.25 GHz

EQUIPMENT TYPE: Portable Handheld Target Simulator

EQUIPMENT USE: Speed Radar Operation Tester

TARGET SIMULATION WITH AGD RADARS: AGD330  
AGD340

TRANSMITTER Power: 5.01 mW e.i.r.p.

ANTENNA TYPE: Patch Antenna

CHANNEL SPACING: Wideband

NUMBER OF CHANNELS: 1

FREQUENCY GENERATION: External Source ☒ Crystal ☐ Synthesiser ☐

MODULATION METHOD: Amplitude ☒ Digital ☐ Angle ☐

POWER SOURCE(s): +3.0Vdc

TEST DATE(s): 23<sup>rd</sup> January – 12<sup>th</sup> February 2009


ORDER No(s): 40758

APPLICANT: AGD Systems Ltd

TESTED BY: ..... D WINSTANLEY

APPROVED BY: ..... J CHARTERS  
RADIO  
PRODUCT  
MANAGER

RU15509030



**CERTIFICATE OF CONFORMITY & COMPLIANCE**

PURPOSE OF TEST: Radio Performance Testing

TEST SPECIFICATION(s): ETSI EN300 440-2V1.1 2.07.2004

TEST RESULT: Compliant to Specification

EQUIPMENT UNDER TEST: AGD932

BAND(s) OF OPERATION: EU 24.00 GHz – 24.25 GHz  
UK 24.05 GHz – 24.15 GHz  
UK 24.05 GHz – 24.25 GHz

EQUIPMENT TYPE: Portable Handheld Target Simulator

EQUIPMENT USE: Speed Radar Operation Tester

TARGET SIMULATION WITH AGD RADARS: AGD330  
AGD340

TRANSMITTER Power: 5.01 mW e.i.r.p.

TRANSMITTER POWER CLASS: Class 11

ANTENNA TYPE: Patch Antenna

CHANNEL SPACING: Wideband

NUMBER OF CHANNELS: 1

FREQUENCY GENERATION: External Source ☒ Crystal ☐ Synthesiser ☐

MODULATION METHOD: Amplitude ☒ Digital ☐ Angle ☐

POWER SOURCE(s): +3.0Vdc

RECEIVER CLASS: Class 3

TEST DATE(s): 23<sup>rd</sup> January – 12<sup>th</sup> February 2009

ORDER No(s): 40758

APPLICANT: AGD Systems Ltd

TESTED BY: ..... D WINSTANLEY

APPROVED BY: ..... J CHARTERS  
RADIO SECTION  
LEADER

RU15509030



**CERTIFICATE OF CONFORMITY & COMPLIANCE**

FCC IDENTITY: WH3AGD932-24

TESTED IN CONJUNCTION WITH FCCID(s): WH3AGD340  
WH3AGD330

PURPOSE OF TEST: Certification

TEST SPECIFICATION: FCC RULES CFR 47, Part 15.249 July 2008

TEST RESULT: Compliant to Specification

EQUIPMENT UNDER TEST: AGD932

ITU EMISSION CODE: 3M612N0N

EQUIPMENT TYPE: Portable Handheld Target Simulator

PRODUCT USE: Speed Radar Operation Tester

CARRIER EMISSION: 123.45 mV/m @3m

ANTENNA TYPE: Patch Antenna

ALTERNATIVE ANTENNA: Not Applicable

BAND OF OPERATION: 24.00 - 24.25GHz

CHANNEL SPACING: Not Applicable, Wideband

FREQUENCY GENERATION: ☒ External Source ☐ Crystal ☐ Synthesiser ☐

MODULATION METHOD: ☒ Amplitude ☐ Digital ☐ Angle ☐

POWER SOURCE(s): +3Vdc

TEST DATE(s): 19<sup>th</sup> January - 12<sup>th</sup> February 2009

ORDER No(s): 40758

APPLICANT: AGD Systems Ltd

ADDRESS: White Lion House  
Gloucester Road  
Staverton  
Cheltenham  
Gloucestershire  
GL51 0TF

TESTED BY: \_\_\_\_\_ D WINSTANLEY

APPROVED BY: \_\_\_\_\_ J CHARTERS  
RADIO SECTION  
LEADER

RU1550/029

TCB

GRANT OF EQUIPMENT  
AUTHORIZATION

Certification  
Issued Under the Authority of the  
Federal Communications Commission  
By:

TCB

Trac EMC & Safety Ltd  
100 Frohisher Business Park Leigh  
Sinton Road, Malvern, Worcestershire  
Malvern, WR14 1BX  
United Kingdom

Date of Grant: 03/17/2009  
Application Dated: 03/17/2009

AGD SYSTEMS LTD  
WHITELION HOUSE, GLOUCESTER ROAD,  
STAVERTON  
CHELTENHAM, GLOUCESTERSHIRE, GL51 0TF  
United Kingdom

Attention: ROBERT FYFE , MR

NOT TRANSFERABLE

EQUIPMENT AUTHORIZATION is hereby issued to the named GRANTEE,  
and is VALID ONLY for the equipment identified hereon for use under the  
Commission's Rules and Regulations listed below.

FCC IDENTIFIER: WH3AGD932-24  
Name of Grantee: AGD SYSTEMS LTD  
Equipment Class: Part 15 Low Power Transceiver, Rx Verified  
Notes: AGD 932 Target Simulator

Grant Notes	FCC Rule Parts	Frequency Range (MHZ)	Output Watts	Frequency Tolerance	Emission Designator
	15C	24050.0 - 24250.0			

## SAFETY PRECAUTIONS

All work must be performed in accordance with company working practices, in-line with adequate risk assessments. Only skilled and instructed persons should carry out work with the product. Experience and safety procedures in the following areas may be relevant:

- Working with mains power
- Working with modern electronic/electrical equipment
- Working at height
- Working at the roadside or highways

1. This product is compliant to the Restriction of Hazardous Substances (RoHS – European Union directive 2011/65/EU).
2. Only the specified access port should be used to access and replace batteries (2x AA).
3. The product must be correctly connected to the specified power supply. All connections must be made whilst the power supply is off or suitably isolated. Safety must always take precedence and power must only be applied when deemed safe to do so.
4. No user-maintainable parts are contained within the product. Removing or opening the outer casing is deemed dangerous and will void all warranties.
5. Under no circumstances should a product suspected of damage be powered on. Internal damage may be suggested by unusual behaviour, an unusual odour or damage to the outer casing. Please contact AGD for further advice.
6. This device complies with part 15 of the FCC Rules.
  - Operation is subject to the following two conditions:
    - (1) This device may not cause harmful interference, and
    - (2) This device must accept any interference received, including interference that may cause undesired operation.
  - This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance such that the module should not be installed in equipment intended to be used within 20cm of the body.
  - The transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
  - Changes or modifications not expressly approved by AGD Systems Ltd could void the user's to operate the equipment.





# DISCLAIMER

While we (AGD Systems) endeavour to keep the information in this manual correct at the time of download or print, we make no representations or warranties of any kind, express or implied, about the completeness, accuracy, reliability, suitability or availability with respect to the information, products, services, or related graphics contained herein for any purpose.

Any reliance you place on such information is therefore strictly at your own risk. In no event will we be liable for any loss or damage including without limitation, indirect or consequential loss or damage, or any loss or damage whatsoever arising from loss of data or profits arising out of, or in connection with, the use of this manual.

## Warranty

All AGD products are covered by a 12 month return to factory warranty. Products falling outside this period may be returned to AGD Systems for: evaluation, repair, update or re-calibration, any of which may be chargeable.

Revision
Issue 6 May 2024



**AGD Systems Pty Ltd**

Unit 17/15 Valediction Road  
Kings Park, NSW 2148

**Tel:** +61 (0) 29653 9934  
**Email:** Admin@agd-systems.com  
**Web:** agd-systems.com.au

